## **MICROSENS**

User Manual – Entry Line Industrial Gigabit Ethernet Switch 4x 10/100/1000Base-T, 10/100/1000Base-T or 100/1000Base-X Combo Port, 1x 100/1000Base-X SFP slot

## **Table of Contents**

| GeneralGeneral               | 3  |
|------------------------------|----|
| Benefits                     | 3  |
| Front View                   | 4  |
| LED Display                  | 4  |
| DIP Switch                   | 5  |
| Dimensional Drawings         | 5  |
| Mounting                     | 6  |
| Power Supply / Alarm Contact | 7  |
| Twisted Pair Connections     | 8  |
| Fiber Connections            | 8  |
| Technical Specifications     | 9  |
| Standard Compliance          | 10 |
| Safety Notes                 | 10 |
| Order Information            | 11 |
| Accessories                  | 11 |

#### General

The IP protocol has already left the in-house environment and is going to take all remaining communication areas. Industrial Ethernet already is an established idea, describing the reliable use of Ethernet components in harsh environments.

Because of the large number of these applications, the market requires simple and also reliable and cost effective products. With the new Industrial Ethernet Entry Line MICROSENS fulfils these requirements. The products are very compact and include:

- 5 and 8 port Fast Ethernet switches
- 6 and 8 Port Gigabit Ethernet switches
- Switches with fiber-uplink
- Media converter for Fast Ethernet and Gigabit Ethernet
- Device Server for the conversion of serial interfaces (RS-232/422/485) to IP.

All new devices distinguish themselves with easy handling (plug & play) and do not need extensive configuration. New developments are focusing on increasing the port numbers and further implementation of Gigabit Ethernet.

#### **Benefits**

#### **System Interface/Performance**

- 4x10/100/1000Base-T ports
- SFP ports support 100Base-FX and 1000Base-X speed
- One SFP/RJ-45 combo port
- Supports auto-negotiation and auto-MDI/MDI-X
- Supports store-and-forward architecture
- Non-blocking data transmission
- Supports 9 kB Jumbo Frames
- Back-plane (Switching Fabric): 12 Gbps
- 1 MB Packet Buffer
- 1K MAC Address Table
- Alarm output relay for power failures


#### **Power Supply**

- 12..56 VDC Redundant Dual Power Input
- Overload current protection
- Reverse polarity protection

#### **Chassis/Installation**

- IP-30 Protection
- DIN-rail and Wall Mount Design

## **Front View**



## **LED Display**

There are diagnostic LED indicators located on the front panel of the industrial switch. They provide real-time information of system and operational status. The following table provides description of the LED status and their meanings for the switch.

| LED       | Color | Status            | Meaning  |
|-----------|-------|-------------------|--|
| D1 Gnan   | On    | Power 1 is active |  |
| P1        | Green | Off               | Power 1 is inactive                                |
| DO        | Cuan  | On                | Power 2 is active                                  |
| P2        | Green | Off               | Power 2 is inactive                                |
| D2        | Cuan  | On                | Power 3 is active                                  |
| P3        | Green | Off               | Power 3 is inactive                                |
| RLY       |       | On                | Power failure (Relay status) P1 or P2 off          |
| (Relay)   | Red   | Off               | No failure   |
|           |       |                   | Valid link established                             |
| Port 1-5  | Green | Off               | No link established                                |
| (Lnk/Act) |       | Flashing          | The port is transmitting or receiving data packets |
| F5/F6     | Green | On                | Valid link at fiber port detected                  |
|           |       | Off               | No valid link at fiber port detected               |
|           |       | Flashing          | The port is transmitting or receiving data packets |

Remark: The right port LED (amber) is not used.

## **DIP Switch**

This unit is equipped with DIP switches, located on the front panel. Adjusting the DIP switches will change the default function of this unit.

| OFF |                               |     |                 |
|-----|-------------------------------|-----|-----------------|
|     | DIP 1 to select<br>port 5 SFP | ON  | F5 OFF          |
|     |                               | OFF | F5 ON (default) |
| 1 2 | DIP 2 to select               | ON  | 100M            |
| ON  | SFP speed                     | OFF | 1000M (default) |

**Warning:** DIP switch function will not work if it is changed when power is connected. Always turn off or disconnect power supply to change DIP switch settings.

# **Dimensional Drawings** $\infty$ 51.7 21.0 36.2 105.0 9.0 0 0 0 0 47. 0 (o) 0 0 0

## Mounting

The industrial switch supports two mounting methods: Wall & DIN-rail.

#### **DIN-Rail Mounting**

You can also mount industrial switch on a standard DIN-rail by below steps.

The DIN-rail kit is screwed on the industrial switch at delivery. If the DIN-rail kit is not screwed on the industrial switch, please screw it on the switch first.

1. First, hang the industrial switch to the DIN-rail with angle of inclination.



Installation to DIN-rail (Step 1)

2. Then, lightly push the DIN-rail into the track.



Installation to DIN-rail (Step 2)

- 3. Check if the DIN-rail is tightened on the track or not.
- 4. To remove the industrial switch from the track, reverse steps above.

#### Wall mounting

The industrial switch can be wall-mounted by using the included mounting kit.


- 1. First, use the screws included in the package to combine the industrial switch and metal mounting kit and remove the DIN-rail adapter.
- 2. Then fix the switch with some screws to the wall.



Wall mounting brackets

## **Power Supply / Alarm Contact**

The power supply is done by an external power supply with an output voltage of 12..56 VDC. This power supply is not included at delivery, but can be ordered separately (e.g. MS700455). The connection is done by the pluggable screw terminals on the top of the device. The connection of a redundant power supply can be done by the second screw terminal. Connect positive wire to P+, negative wire to P-, also connect grounding/ earth wire to the grounding screw. Alternative the power DIN connector P3 can be used.



Pin out Power Connector and Alarm Contact

WARNING: Any exceeded input voltage will not make this unit function and may damage this unit!

Warning: Always ground the power source to maintain a clean power input.

The status of the alarm relay (RLY) contact depends on the power inputs P1 and P2:

| Input power condition   | Relay status |
|-------------------------|--------------|
| Power 1 and 2 connected | Relay open   |
| Power 1 or 2 fails      | Relay closed |
| No power connected      | Relay open   |

Alarm Relay functionality

#### **Twisted Pair Connections**

The integrated auto-crossing function of all twisted pair ports makes the use of crossed patch cables unnecessary. The switch automatically detects the pinout of the connected cable and adapts the port accordingly. For all connections standard 1:1 twisted pair cables can be used.

The Auto-negotiation mechanism detects automatically the speed and transmission mode (full or half duplex) between connected ports. A manual configuration is not required.

#### **Fiber Connections**

This switch is equipped with two SFP slots. MICROSENS offers several SFPs for different distances, data rates and Multimode or Single Mode fibers. Please ensure that the used SFP and the patch cable matches with the fiber of the building installation.

Standard SFP transceivers are equipped with a LC duplex interface. One port operates as transmitter (TX), the other one as receiver (RX).

Two fiber optic transceivers are connected together by connecting the transmitter of the first module with the receiver of the second one and vice versa.

For special applications simplex SFP transceivers are available. They can be connected together with one single fiber. An internal optical filter separates the TX and RX path.

## **Technical Specifications**

**Type** Gigabit Ethernet Switch 4x 10/100/1000Base-T, 1x

10/100/1000Base-T or 100/1000Base-X SFP Combo Port, 1 x 100/1000X SFP slot (100 Mbps and 1 Gbps)

**Fiber type** Multimode or Single Mode (Depending on used SFP)

**Cable type** Unshielded/shielded twisted pair cable, 100 Ohm,

min. category 5e

**Data rate** 10, 100 or 1000 Mbps

**LED displays** Power 1/2/3 (green)

Alarm relay status (amber)
Per TX Port: (link / activity)
Per FX Port: (link / activity)

**Mounting** 35 mm top-hat rail, according DIN EN 50 022 optional

wall mounting set

Power supply 12..56 VDC

connections with screw terminals, redundant ports,

additional 4-pin power DIN connector (P3)

**Power / relay wiring** Wire range: 0.34 mm<sup>2</sup> to 2.5 mm<sup>2</sup>

Solid wire (AWG):12-24 / 14-22 Stranded wire (AWG): 12-24 / 14-22 Torque:5 lb-In / 0.5 Nm / 0.56 Nm

Wire Strip length: 7-8 mm

**Power consumption** Typ. 5.8 W @ 48 VDC (full load)

**Alarm relay** 1 A / 24 V max.

**Dimensions**  $36.2 \times 105 \times 142 \text{ mm (w x d x h)}$ 

**Operating temp.** -40° C to 75° C

**Storage temp.** -40° C to 85° C

**Rel. humidity** 5% to 95% non-condensing

EMI EN 55022 class A

**EMS** EN 61000-4-2 (ESD), EN 61000-4-3 (RS),

EN 61000-4-4 (EFT), EN 61000-4-5 (Surge),

EN 61000-4-6 (CS), EN 61000-4-8, EN 61000-4-11

**Shock** EN 60068-2-27

Free fall EN 60068-2-32

**Vibration** EN 60068-2-6

**Safety** EN 60950-1

**CE** 2014/30/EU EMC Directive

2011/65/EU RoHS Directive

## **Standard Compliance**

#### **IEEE Standards**

• IEEE 802.3 10Base-T Ethernet

- IEEE 802.3u 100Base-TX Fast Ethernet
- IEEE 802.3ab 1000Base-T Gigabit Ethernet
- IEEE 802.3z 1000Base-X Gigabit Ethernet

## **Safety Notes**

**WARNING:** Infrared radiation as used for data transmission within the fiber optic, although invisible to the human eye, can nevertheless cause damage.

To avoid damage to the eyes:

- never look straight into the output of fiber optic components danger of blinding!
- cover all unused optical connections with caps.
- commission the transmission link only after completing all connections.

The active laser components used with this product comply with the provisions of **Laser Class 1**.

**DANGER:** Conductive components of power and telecommunications networks can carry dangerously high voltage.

To avoid electric shock:

- Do not carry out installation or maintenance work during lightning storms.
- All electric installations must be carried out in accordance with local regulations.

## **Order Information**

| ArtNo. | Description  | Connectors                                       |
|--------|--|--|
|        | Industrial Gigabit Ethernet Switch, Entry Line, 4x 10/100/1000Base-T, 1x 10/100/1000Base-T or 100/1000Base-X SFP Combo Port, 1x 100/1000X SFP Port | 2x SFP slots<br>5x RJ-45<br>2x Power<br>1x Alarm |

## **SFP Optical Transceivers**

| ArtNo.     | Description   | Connectors |
|------------|---|------------|
| MS100190DX | SFP Pluggable Transceiver Fast Ethernet 1310nm<br>Multimode LC, ext. temp. range -4085°C                        | LC duplex  |
| MS100191DX | SFP Pluggable Transceiver Fast Ethernet 1310nm Single Mode LC, ext. temp. range -4085°C                         | LC duplex  |
| MS100200DX | SFP Pluggable Transceiver Gigabit Ethernet 850nm<br>Multimode LC, ext. temp. range -4085°C                      | LC duplex  |
| MS100210DX | SFP Pluggable Transceiver Gigabit Ethernet, 1310nm Single Mode FP Laser min. 10km, LC, ext. temp. range -4085°C | LC duplex  |

## **Accessories**

| ArtNo.   | Description  | Connectors              |
|----------|--|-------------------------|
| MS700455 | DIN Rail mounting power supply 50 Watt 48VDC/1.05 A, input voltage 85–264 VAC, screw terminals, temp. range -10°C70°C        | In: 3-pin<br>Out: 4-pin |
| MS700456 | DIN Rail mounting power supply 120 Watt 48VDC/2.5 A, input voltage 93-132/180-264 VAC, screw terminals, temp. range 35°C70°C | In: 3-pin<br>Out: 6-pin |
| MS700457 | DIN Rail mounting power supply 240 Watt 48VDC/5 A, input voltage 93-132/180-264 VAC, screw terminals, temp. range -35°C70°C  | In: 3-pin<br>Out: 6-pin |

MICROSENS reserves the right to make any changes without further notice to any product to improve reliability, function or design. MICROSENS does not assume any liability arising out of the application or use of any product. 0117sh

www.microsens.com